





FRE + FGT FRE + FRC + FGT



INS-FRE-2018-10 (04/27)



FRE
2-17

FRE + FRC
18-39







40

02

FRE	A	B
0606	600-610	600-610
0808	800-810	800-810
0609	600-610	900-910
0909	900-910	900-910
0912	900-910	1200-1210
1010	1000-1010	1000-1010
1015	1000-1010	1500-1510
1212	1200-1210	1200-1210

03

04 FGT B200



18

FRE	A	B
0606	600-610	600-610
0808	800-810	800-810
0609	600-610	900-910
0909	900-910	900-910
0912	900-910	1200-1210
1010	1000-1010	1000-1010
1015	1000-1010	1500-1510
1212	1200-1210	1200-1210

19

20

FGT B200

21a

FRC..F

FRC..F

A/B

21b

FRC, FRC..F

FRC

FRC..F

A/B

22

FRC..F

23

FRC..F

24

FRC

25

FRC

26

27

28

29

30

31

32

33

34

35

36

37

38

39

FGT B200

40

FGT B200

